SETTING UP SICAT SMART

With **SICAT Smart**, you use the SICAT Suite applications based on a subscription plan.

In this **quick guide**, you will learn how to set up **SICAT Smart**.

Before you start
- Please read the complete quick guide before you begin.
- For comprehensive product information, please use the instructions for use of the SICAT Suite applications. These are available online at *https://www.sicat.com/manuals*.

Step 1: Check the system requirements

Please check whether the computer on which you want to use **SICAT Smart** meets the system requirements that you can find online at *https://www.sicat.com/products/#system-requirements*.

Step 2: Register in the SICAT Portal

1. Open the *https://portal.sicat.com* website in a web browser.
2. If you have not yet registered in the **SICAT Portal**, click the **Register as new user** link and follow the instructions. Otherwise, you can skip this step.

   You will receive a confirmation email and can now log in to the **SICAT Portal** with your access data.

Step 3 (optional): Redeem existing vouchers

1. Log in to the **SICAT Portal** using your access data, click on **Redeem voucher** and follow the instructions.

   You will automatically be forwarded to the configuration of **SICAT Smart** (step 4).

Step 4: Set up SICAT Smart

1. Log in to the **SICAT Portal** using your access data and click **SICAT Smart** on the Dashboard. Check the configuration of your subscription, enter your payment information and follow the instructions.

   You will automatically be forwarded to the download of **SICAT Connect**.

Step 5: Install SICAT Connect

1. Download **SICAT Connect** and install **SICAT Connect** on all computers on which you want to use **SICAT Suite**.
2. To link **SICAT Connect** with your SICAT Portal account, log in to **SICAT Connect** using your **SICAT Portal** access data and follow the instructions.

   SICAT Connect checks if **SICAT Suite** is already available on your computer. If not, you will be redirected to the download of **SICAT Suite**.

Step 6: Install SICAT Suite

1. Download **SICAT Suite** from the **SICAT Portal**.
2. Install **SICAT Suite** on your computer.

SICAT